

Eye lens doses for medical staff performing interventional procedures

Lara Struelens
Radiation Protection Dosimetry and Calibration




Lara.struelens@sckcen.be



STUDIECENTRUM VOOR KERNENERGIE
CENTRE D'ETUDE DE L'ENERGIE NUCLEAIRE

- Introduction
- Overview of eye lens doses for medical staff
- Radiation Protection of the eye
- Monitoring of eye lens doses
- Conclusion

- Cataract: “loss of transparency of the eye lens”
 - Light not properly focused on the retina
 - Starts with lens opacities: no visual impact



- Associated with aging and metabolic conditions, like diabetes
- Also radiation-induced

- Previous status radiation protection ICRP
 - Cataract induction = deterministic effect with definite threshold
 - Acute exposure: 0,5 – 2 Gy
 - Prolonged exposure: 5-6 Gy
 - Latency period that can last for decades
 - Dose limits
 - 150 mSv/year for occupational exposure
- Recent developments*: epidemiological studies
 - A-bomb survivors, Chernobyl clean-up workers, radiological technologists, ...
 - High probability that threshold dose < 0,8 Gy
 - Not certain there is a threshold
 - Current limit is too high

* Ainsbury EA, Bouffler SD, Dorr W, Graw J, Muirhead CR, Edwards AA, Cooper J. *Radiation cataractogenesis: a review of recent studies. Radiat Res* 2009; 172:1-9

- ICRP recommendations
 - **ICRP-103** (2007): recommends review of and evaluation of non-cancerous effects of ionising radiation on normal tissue
 - **ICRP-118** (2012): ICRP Statement on Tissue Reactions / Early and Late Effects of Radiation in Normal Tissues and Organs – Threshold Doses for Tissue Reactions in a Radiation Protection Context

Cataract:

- **Threshold dose of 0,5 Gy** irrespective of the rate of dose delivery
- Dose limits: **20 mSv/year for occupational exposure**
(averaged over 5 years, with not more than 50 mSv/year)

- Potentially serious implications for some health care professionals
 - medical staff performing interventional procedures



Eye lens doses for medical staff

- EU funded ORAMED project (2008-2011)

“ **O**ptimization of **R**adiation protection for **MED**ical staff ”




- Overview of eye lens dose measurements

- Interventional radiologists and cardiologists (>1300 interventional procedures)
- 6 different countries

- Eye lens doses from **10 μ Sv to 4 mSv per procedure**
(median value of 60 μ Sv)
- Cumulative **annual eye lens doses from < 1 mSv to 150 mSv**



- Considerable number (**24%**) exceed the annual dose limit of 20 mSv



Eye lens doses for medical staff

- Belgian ExDos project (2008-2011): financed by FANC
“Overview of extremity doses and eye lens doses for interventional procedures and nuclear medicine in Belgium ”

- Overview of eye lens dose measurements
 - 2 Belgian partners: SCK•CEN and UZ-Brussel
 - Belgian extension of ORAMED
 - Extension of measurements from 3 hospitals to 10 hospitals
 - Extra procedure: spine procedures (vertebroplasty and kyphoplasty)



- Eye lens doses from **10 μSv to 836 μSv per procedure** (median value of 34 μSv)
- Cumulative **annual eye lens doses from < 1 mSv to 61 mSv**

Eye lens doses for medical staff

- Recent epidemiological studies

- French O'CLOC study*

- 106 Interventional cardiologists and 99 unexposed individuals
- Posterior subcapsular lens opacities: **17% vs. 5%, p<0.05**

* *Jacob S, Boveda S, Bar O, Brézin A, Maccia C, Laurier D, Bernier MO. Interventional cardiologists and risk of radiation-induced cataract: Results of a French multicenter observational study. Int J Cardiol. 2012 May 17*

- Finnish study

- 16 interventional cardiologists + 20 interventional radiologists
- **Cortical and PSC lens opacities**



- IAEA study**: survey at cardiology conference

- 58 cardiologists, 69 technicians
- Posterior subcapsular lens changes:
 - » **50% vs <10% (cardiologists) and 41% vs <10% (technicians)**

** *Vano E, Kleiman NJ, Duran A, Romano-Miller M and Rehani MM. Radiation-associated Lens Opacities in Catherization Personnel: Results of a Survey and Direct Assessments. J Vasc Interv Radiol 2013; 24:197-204*

Radiation protection of the eye


- Medical staff exposed by scattered radiation from the patient
- Protect the eye with
 - lead ceiling-mounted screens




www.oramed-fp7.eu

Radiation protection of the eye

- Medical staff exposed by scattered radiation from the patient
- Protect the eye with
 - lead ceiling-mounted screens




www.oramed-fp7.eu





Radiation protection of the eye

- Medical staff exposed by scattered radiation from the patient
- Protect the eye with
 - lead glasses



Radiation protection of the eye

- Medical staff exposed by scattered radiation from the patient
- Protect the eye with
 - lead glasses



Result:

Ratio with/without lead glasses for any interventional procedure and tube configuration

Left eye = 0.13 (20%)

Right eye = 0.84 (15%)

- www.oramed-fp7.eu
- European ELDO project

Monitoring of eye lens doses

- Need to follow up the eye lens dose
 - for medical staff at risk to exceed annual eye lens dose limit
- ORAMED: development and validation of eye lens dosemeter "EYE-D"
 - Measuring in terms of $H_p(3)$ dose quantity



RADCARD, Poland

Monitoring of eye lens doses



- Need to follow up the eye lens dose
 - for medical staff at risk to exceed annual eye lens dose limit
- ORAMED: development and validation of eye lens dosimeter "EYE-D"
 - Measuring in terms of Hp(3) dose quantity
 - Practical problems: ergonomics of the system
 - Difficult to use in combination with lead glasses
 - Increase of number of dosimeters per person
 - Risk of exceeding dose limit, depend on medical speciality
- **Alternative method to assess eye lens dose??**

Monitoring of eye lens doses

- European ELDO project (funded by DoReMi network)

“Correlation between eye lens dose and whole body dose”

- Measurement of eye lens doses and whole body doses in clinical conditions
 - Operator: Rando-Alderson phantom
 - Patient: PMMA plates
 - Passive and active dosimeters
 - Measurements above the lead apron
 - Eye level
 - Collar level
 - Chest level
 - Waist level
 - Left – middle – right side



Monitoring of eye lens doses


- European ELDO project (funded by DoReMi network)

“Correlation between eye lens dose and whole body dose”

- Clinical conditions
 - Different x-ray beam projections
 - Different operator positions with respect to the x-ray field
 - Different x-ray beam energies
 - Mono-plane and bi-plane x-ray systems

**Result = ratio [eye lens dose/whole body dose]
and associated uncertainty**

- Without protection equipment
(lead glasses and ceiling-mounted screen)



Monitoring of eye lens doses

- All measurement configurations together (48 cases)

Ratio of average **left eye** lens dose and whole body dose measured at different locations, considering **all projections and operator positions**.

	Collar L	Collar M	Collar R	Chest L	Chest M	Chest R	Waist L	Waist M	Waist R
Ratio	3.3	2.1	11.5	0.8	1.2	2.5	1.5	1.8	8.0
Standard deviation	42%	48%	81%	90%	73%	100%	159%	143%	147%

Best correlation

Ratio of average **right eye** lens dose and whole body dose measured at different locations, considering **all projections and operator positions**.

	Collar L	Collar M	Collar R	Chest L	Chest M	Chest R	Waist L	Waist M	Waist R
Ratio	2.7	1.7	8.6	0.7	0.9	1.8	1.3	1.6	6.2
Standard deviation	42%	45%	73%	90%	58%	101%	164%	153%	155%

Monitoring of eye lens doses

- Measurement per type of procedure

Ratio of average **left eye** lens dose and whole body dose measured at different locations, considering projections and operator positions for **CA&PTCA** and **RF ablations**.

	Collar L	Collar M	Collar R	Chest L	Chest M	Chest R	Waist L	Waist M	Waist R
Ratio	4.0	2.6	12.8	0.7	1.0	1.9	0.5	0.7	3.7
Standard deviation	41%	40%	56%	52%	56%	50%	46%	64%	101%




Ratio of average **left eye** lens dose and whole body dose measured at different locations, considering projections and operator positions for **pacemaker procedures**.

	Collar L	Collar M	Collar R	Chest L	Chest M	Chest R	Waist L	Waist M	Waist R
Ratio	3.4	2.4	8.2	0.7	0.9	1.7	0.5	0.7	2.7
Standard deviation	36%	52%	70%	23%	41%	35%	40%	52%	87%


Reduced uncertainties

Monitoring of eye lens doses

- Influence of **the use of protection equipment** on these ratio's
- Monte Carlo calculations
 - Variation of eye lens dose and whole body dose with
 - Shape of lead glasses
 - Thickness of lead
 - Position and shape of ceiling-mounted lead screen
 - For all possible x-ray projections, operator positions and x-ray tube configurations



Lead
eye
glasses



Result = correction coefficients considering effect of protection and associated uncertainty

Monitoring of eye lens doses

- Effect of ceiling shield (19 cases)

Ratio of dose **with/without ceiling-mounted lead screen**, considering all projections and operator positions.

	Eyes	Collar	Chest	Waist
Ratio	0.51	0.63	0.75	0.82
Standard deviation	70%	54%	34%	22%

- Effect of lead glasses (27 cases)

Ratio of dose **with/without lead glasses**, considering all projections and operator positions.

Large influence of glasses shape

- Rounded model: 0.17
- Squared model: 0.63

More calculations on-going !!!

	Left Eye	Right Eye
Ratio	0.13	0.84
Standard deviation	20%	15%

PRELIMINARY

Monitoring of eye lens doses

Summary

- The correlation between eye lens and whole body dose depends on
 - Type of procedure
 - The position of the whole body dosimeter (always ABOVE lead apron)
 - The working practice
 - position of operator
 - The use of protective equipment
- Assessing eye lens dose from whole body dose can introduce **large uncertainties**
(40% to 160% without protection ; additional 15% to 70% for use of protection)
 - This method is first evaluation of eye lens dose
 - If assessed dose is high: specific person can benefit from wearing eye lens dosimeter routinely
- Useful for future retrospective epidemiological study of this population

- Medical staff performing interventional procedures is at risk of exceeding annual dose limit for the eye lens (20 mSv)
 - Measured eye lens doses are high, especially if no protection is used
 - Recent epidemiological studies show increased prevalence of lens opacities for this population
- Monitoring eye lens dose is crucial
 - First evaluation possible from whole body dose records (above the lead apron)
 - Lack of practical eye lens dosimeter
 - Also to be used in combination with lead glasses
- At least as important is the awareness from the medical staff of the risk and the implementation of protection tools
 - Eye lens doses can be significantly reduced if lead glasses and ceiling-mounted shields are **properly** used

- More research is continuously performed related to the dose-response of radiation-induced lens opacities in the low-dose range
- Currently preparing an **European** epidemiological study on radiation-induced cataract for interventional cardiologists
 - Several European countries are preparing the creation of a national cohort using the same protocols (ELDO project)
 - Joined analysis of the pooled European cohort
 - To elucidate further the reduction of the threshold for cataract (ICRP-118)
 - To confirm if there is a threshold
- Belgium is also participating in this study and in preparation of creating a national cohort of interventional cardiologists
 - Retrospective assessment of eye lens doses
 - Performance of ophthalmological examinations

Thank you for your attention !!!



Copyright © 2013 - SCK•CEN

PLEASE NOTE!

This presentation contains data, information and formats for dedicated use ONLY and may not be copied, distributed or cited without the explicit permission of the SCK•CEN. If this has been obtained, please reference it as a "personal communication. By courtesy of SCK•CEN".

SCK•CEN

Studiecentrum voor Kernenergie
Centre d'Etude de l'Energie Nucléaire
Belgian Nuclear Research Centre

Stichting van Openbaar Nut
Fondation d'Utilité Publique
Foundation of Public Utility

Registered Office: Avenue Herrmann-Debrouxlaan 40 – BE-1160 BRUSSELS

Operational Office: Boeretang 200 – BE-2400 MOL



STUDIECENTRUM VOOR KERNENERGIE
CENTRE D'ETUDE DE L'ENERGIE NUCLEAIRE